

RAPTOR TRUCK BED LINER



Lightly abrade original manufacturer's finish using sander with **U-POL P240 grit disc**, or by hand with **U-POL Red Finishing Pad**. Treat any bare metal surface with **U-POL ACID#8 Etch Primer**.



Clean entire surface with **U-POL Degreaser**. Use **U-POL Clear Masking Film** to protect areas not to be sprayed.



Add **U-POL System20 Hardener** directly into **Raptor** bottle up to level A (see product instructions). For tintable version, add basecoat tinter to level B. For option to apply using a **HVLP spraygun**, add up to 10% **U-POL System20 Fast Thinners**.



Replace cap and shake vigorously for 2minutes to activate mix. Remove cap and attach **U-POL Raptor** bottle directly to suction shutz gun.



Apply to truck bed with an even sweeping motion to obtain required texture. Allow 60minute flash off period between coats. Allow to cure according to recommended guidelines.

Products required for performing this process:



Coating Products:

RAPTOR Spray-On Liner (Black, Tintable)

4L Kit (incl. hardener)

Associated Coatings:

S2030 Fast Hardener

250ml, 330ml, 500ml, 1L, 2.5L, 5L Tin

S2031 Extra Fast Hardener

330ml, 500ml, 1L, 2.5L Tin

S2032 Standard Hardener

330ml, 500ml, 1L, 2.5L, 5L Tin

S2033 Slow Hardener

330ml, 500ml, 1L, 2.5L Tin

S2040 Thinners Range (for spraygun application)

1L, 5L Tin

Other Products:

S2000 Water Based Degreaser

5L Tin

S2001 & S2002 Solvent Based Degreasers (Fast & Slow)

1L, 5L Tin, 500ml Aerosol

Maximum Abrasive Paper Discs P240 grit

100 discs

Shutz Thick Coating Spray Gun

ACID#8 Acid Etch Primer Aerosol

450ml Aerosol